
Estimation of Effective Cake Filtration Simulation Parameters from Resolved Filtration Simulations

Interpore 2016 Cincinnati, Ohio May 12th, 2016

Sven Linden

Jürgen Becker Liping Cheng Andreas Wiegmann







Math2Market GmbH

Some background information

- Math2Market creates and markets software for engineers and scientists that want to analyze and design porous and composite materials based on the material's geometric inhomogeneity.
- The materials can come from µCT, FIB-SEM or models and are represented as 3-dimensional images in the software.
- This software is called GeoDict, the Digital Material Laboratory.
- M2M is based in Kaiserslautern, Germany.
- M2M is an institutional member of InterPore.
- M2M spun off from Fraunhofer Institute for Industrial Mathematics, a founding institute of InterPore.


Visit us at our booth




The Regimes of Fluid-Solid Filtration

In fluid-solid filtration processes, solid particles are carried by a fluid (liquid or gas) and trapped inside a filter media or on top of a filter media.

- Trapping inside the filter media is called depth filtration
- Trapping on top of the filter media is called cake filtration
 - In cake filtration, the filtration is achieved primarily by previously deposited particles, not so much by the filter media.





Cake Filtration






Scale Issue of Cake Filtration Simulation on Uniform 3d Grids


- While the inhomogeneity of the filter media may be on a single scale, poly-disperse particles usually span multiple scales.
- When all particles are much smaller than the computational grid size, then an homogeneous porous media approach works.
- When all particles are much larger than the grid size, then solid and empty cells suffice to represent them.
- When the particle size distribution includes larger particles and smaller particles than the grid size, then sub-grid resolution and parameters for inhomogeneous porous media are required.
- We describe two procedures by which these parameters can be found.






1. Filter Model










2. Flow Field














3. Track Particles








e**l**


2. Flow Field

4. Deposit Particles







1. Filter Model




2. Flow Field



3. Track Particles




4. Deposit Particles




5. Flow Field







1. Filter Model




2. Flow Field




3. Track Particles



4. Deposit Particles




5. Flow Field



6. Repeat ...

Computational Grid, Resolved & Unresolved Particles

Computational Grid




Resolved Particle

Unresolved Particles



Discretization of Resolved and Unresolved Particles

Computational Grid



Resolved Particle

Unresolved Particles


Empty/Solid Cells

Porous Cells





Mixed Resolved & Unresolved Particles for Varying Resolutions



SVF from resolved 3d simulation (voxel length 0.5µm) upscaled by post-processing.

SVF=0 (empty)

0<SVF<1 (porous)

SVF=1 (solid)





- Voxels are solid or empty
- Stationary incompressible Navier-Stokes equation

$$-\mu\Delta\vec{u} + \rho(\vec{u}\cdot\nabla)\vec{u} + \nabla p = 0, \qquad \nabla\cdot\vec{u} = 0$$

$$\mu$$
 viscosity ρ density u velocity p pressure

Particles are discretized into solid/empty grid cells

Output parameters: f_{max} (maximal solid volume fraction) and σ_{max} (maximal flow resistivity)

Unresolved Particles









- Voxels are solid, empty or porous
- Stationary incompressible Navier-Stokes-Brinkman equation

$$-\mu\Delta\vec{u} + \rho(\vec{u}\cdot\nabla)\vec{u} + \frac{\mu}{\kappa}\vec{u} + \nabla p = 0,$$

$$\nabla \cdot \vec{u} = 0$$

 κ : permeability

In porous voxels:

- Local solidity f changes when a particle is added.
- When f_{max} is reached, no more particles can be added.
- Local flow resistivity:

$$\sigma = \frac{\mu}{\kappa} = \begin{cases} \frac{f}{f_{max}} \sigma_{max} & \text{for } 0 < f < f_{max} \\ \sigma_{max} & \text{for } f_{max} \le f \le 1 \end{cases}$$


 σ_{max} Resistivity f_{max}

Math2Market GmbH

Input parameters: f_{max} (maximal solid volume fraction) and σ_{max} (maximal flow resistivity)

Unresolved Particles





Particle



Example: Soot filtration – ceramic filter; caught on first touch model



Unresolved Particles











Example: Soot filtration – ceramic filter; caught on first touch model








Simulation Setup



- No depth filtration, only cake filtration
- Unresolved filter media: 48 µm thick, fixed permeability
- Particles are caught on first touch
- Particle diameter range between 1µm and 15µm
- 1. Vary resolution between 0.5 µm per voxel and 24 µm per voxel
- 2. Determine flow resistivity and cake solidity




Comparison: Computations with Resolved Particles vs Partially Resolved Particles and up to Unresolved Particles



Resolved Particles Caught On First Touch

Resolution 0.5µm



Result:


- Flow resistivity 14.4 e+6 kg/m³s
- Cake solidity 0.1953





Fully Unresolved Particles Caught On First Touch

Resolution 24µm



Input (porous voxels):

$$\sigma_{max} = 14.4 \text{ e+6 kg/m}^3 \text{s}$$

 $f_{max} = 0.1953$

Result:

- Flow resistivity 14.3 e+6 kg/m³s
- Cake solidity 0.2027





Results for Partially Resolved Particles with Parameters for Unresolved Particles

Resolution	Input Pa	rameters	Resulting Cake	
	f _{max}	σ _{max} [10 ⁶ kg/m ³ s]	Solidity	Flow Resistivity [10 ⁶ kg/m³s]
24 µm	0.1953	14.4	0.2027	14.34
8 µm	0.1953	14.4	0.1953	10.17
4 μm	0.1953	14.4	0.1422	4.02
2 µm	0.1953	14.4	0.1346	3.09
1 µm	0.1953	14.4	0.1535	4.41
0.5 μm	solid/empty	solid/empty	0.1953	14.40





Results for Partially Resolved Particles with Parameters for Unresolved Particles

Resolution	Input Parameters		Resulting Cake	
	f _{max}	σ _{max} [10 ⁶ kg/m ³ s]	Solidity	Flow Resistivity [10 ⁶ kg/m³s]
24 µm	0.1953	14.4	0.2027	14.34
8 µm	0.1953	14.4	0.1953	10.17
4 µm	0.1953	14.4	0.1422	4.02
2 µm	0.1953	14.4	0.1346	3.09
1 µm	0.1953	14.4	0.1535	4.41
0.5 µm	solid/empty	solid/empty	0.1953	14.40

Solidity too low Need higher f_{max}





Results for Partially Resolved Particles with Parameters for Unresolved Particles

Resolution	Input Parameters Res		Resultii	sulting Cake	
	f _{max}	σ _{max} [10 ⁶ kg/m ³ s]	Solidity	Flow Resistivity [10 ⁶ kg/m³s]	
24 µm	0.1953	14.4	0.2027	14.34	
8 µm	0.1953	14.4	0.1953	10.17	
4 µm	0.1953	14.4	0.1422	4.02	
2 µm	0.1953	14.4	0.1346	3.09	
1 µm	0.1953	14.4	0.1535	4.41	
0.5 μm	solid/empty	solid/empty	0.1953	74.40	

Solidity too low Need higher f_{max}

Resistivity too low Need higher σ_{max}

© Math2Market GmbH





Resolution 4 µm

Input Parameters		Resulting Cake		
f _{max}	σ _{max} [10 ⁶ kg/m ³ s]	Solidity	Flow Resistivity [10 ⁶ kg/m³s]	
0.1953	14.40	0.1422	4.02	
0.4000	200.00	0.2505	50.00	





Resolution 4 μm

1. Use result of resolved model

Input Parameters		Resulting Cake		
f _{max} σ _{max} [10 ⁶ kg/m ³ s]		Solidity	Flow Resistivity [10 ⁶ kg/m³s]	
0.1953	14.40	0.1422	4.02	
0.4000	200.00	0.2505	50.00	





Resolution 4 µm		Input Parameters		Resulting Cake	
		f _{max}	σ _{max} [10 ⁶ kg/m ³ s]	Solidity	Flow Resistivity [10 ⁶ kg/m³s]
Use result of resolved model		0.1953	14.40	0.1422	4.02
2. Use other values		0.4000	200.00	0.2505	50.00





Resolution 4 µm	Input Parameters		Resulting Cake	
	f _{max}	σ _{max} [10 ⁶ kg/m ³ s]	Solidity	Flow Resistivity [10 ⁶ kg/m³s]
1. Use result of resolved model	0.1953	14.40	0.1422	4.02
3. Assume linear dependency solidity from f_{max} \Longrightarrow resistivity from σ_{max}	0.2956	56.34	0.1904	13.50
2. Use other values	0.4000	200.00	0.2505	50.00





Results for Mixed Resolutions with Fitted Parameters

Resolution	Input Parameters		Resulting Cake		
	f _{max}	σ _{max} [10 ⁶ kg/m ³ s]	Solidity	Flow Resistivity [10 ⁶ kg/m³s]	
24 µm	0.1953	14.4	0.2027	14.3	
8 µm	0.1953	20.19	0.1967	14.4	
4 µm	0.2956	56.34	0.1904	13.5	
2 µm	0.4600	170.00	0.1949	13.8	
1 µm	0.5000	441.50	0.1928	15.2	
0.5 μm	solid/empty	solid/empty	0.1953	14.4	






Questions:

- Do local solidity and local flow resistivity distributions match for resolved and mixed resolution computations?
- Can we estimate f_{max} and σ_{max} from just a single resolved cake filtration simulation?
 - Reduce estimation effort from three to one simulation
 - Develop a theory or provide a data base with effective parameters depending on particle size distribution and grid resolutions







Comparison of σ – SVF Distribution





Comparison of SVF Probability Density





Comparison of SVF Cumulative Probability











- SVF probability of fully and partially resolved particles match
- Cumulative probability between 60% and 80% at f_{max}

Conclusions And Outlook

- Cake formation can be modeled at different resolutions
- Parameters f_{max} and σ_{max} can be estimated by linear fitting
- Local solidity and flow resistivity of fully and partially resolved computations match
- The σ function for different resolutions can be estimated from fully resolved computations
- Open questions:
 - How to estimate f_{max} from one fully resolved cake filtration?
 - Can the f_{max} , σ_{max} model be replaced?



GEODICT

The Digital Material Laboratory

Standard Edition

© 2012 - 2015 Math2Market GmbH © 2001 - 2012 Fraunhofer ITWM All rights reserved.

info@math2market.de www.geodict.com

Software Design:
Dr. Jürgen Becker, Liping Cheng, PhD,
Dr. Erik Glatt, Dr. Sven Linden,
Dr. Christian Wagner, Dr. Rolf Westerteiger,
Nicolas Harttig, Andreas Grießer,
and Andreas Wiegmann, PhD

Art Design: Steffen Schwichow

















Visit us @ www.geodict.com



