


GEO DICT

High Performance Computing

User Guide

GeoDict release 2023

Published: May 22, 2023



GEO DICT

<https://doi.org/10.30423/userguide.geodict>

© Math2Market GmbH 2023

Citation:

Sven Linden, Andreas Wiegmann, Jürgen Becker, Aaron Widera, Barbara Planas. GeoDict 2023 User Guide. GeoDict – High Performance Computing handbook. Math2Market GmbH, Germany, doi.org/10.30423/userguide.geodict

All rights reserved. It is not permitted to reproduce the book or parts thereof in any form by photocopy, microfilm or other methods or to transfer it into a language suitable for machines, in particular data processing systems, without the express permission of the publisher. The same applies to the right of public reproduction.

The handbooks in the User Guide series of Math2Market GmbH can be obtained from:

Math2Market GmbH
Richard-Wagner-Strasse 1
67655 Kaiserslautern
Germany

Phone: +49 631 205 605 0
Fax: +49 631 205 605 99
Email: info@math2market.de
Web: www.math2market.de

INTRODUCTION TO HIGH PERFORMANCE COMPUTING	1
SHARED MEMORY MACHINES	1
COMPUTER CLUSTERS	2
CLOUD SERVICES	2
GEO_DICT CLOUD	3
MATH2MARKET CLOUD	3
PARALLELIZATION AND CONFIGURATION OF MPI	5
PARALLELIZATION OPTIONS	5
INSTALLATION OF MPI	7
SWITCH BETWEEN DIFFERENT MPI PACKAGES	8
GRAPHICAL REMOTE DESKTOP CONNECTION TO LINUX COMPUTER	10
INSTALL TURBOVNC ON THE REMOTE LINUX COMPUTER	10
INSTALL VIRTUALGL ON THE REMOTE LINUX COMPUTER	10
INSTALL TURBOVNC ON THE LOCAL WINDOWS COMPUTER	11
START TURBOVNC SERVER ON THE LINUX COMPUTER	12
CONNECT WINDOWS TO A REMOTE LINUX COMPUTER	13
START AND RUN GEODICT ON THE REMOTE LINUX COMPUTER	13
CLUSTER COMPUTING ON LINUX CLUSTERS	14
ENABLE PASSWORD-LESS LOGIN	14
PREPARE A CLUSTER SIMULATION SCRIPT	14
START A SIMULATION ON THE CLUSTER	16
CHOICE OF COMPUTE NODES	16
CLOUD COMPUTING	17
GEO_DICT CLOUD	17
Registration	17
Running a Single Simulation in the Cloud	18
SELECT A MACHINE	19
START THE SIMULATION	20
THE KALEIDOSIM DASHBOARD	21
DOWNLOAD RESULTS	22
Running Parameter Studies in the Cloud	24
MATH2MARKET CLOUD	27
Log into your M2M Cloud VM workstation	27
Manage data in the dashboard	27
RUNNING VIRTUAL WORKSTATIONS	28
PROJECT DATA	28
Create a new M2M Cloud VM workstation	29
Access the created M2M Cloud VM workstation	30

Start GeoDict in the new M2M Cloud VM workstation	31
Copy Result Data to the Dashboard	31
Viewer settings for your running M2M Cloud VM workstation	32
Terminate the running M2M Cloud VM workstation	33

INTRODUCTION TO HIGH PERFORMANCE COMPUTING

Three-dimensional computer tomography images can consist of 2000^3 or even more voxels. **GeoDict** allows to compute flow, thermal, electrical or mechanical properties on such large datasets. In these computations, multiple floating point values per grid cell must be computed and stored. As 2000^3 already means 8 billion grid cells, such computations need strong computational resources. These simulations require:


1. a large amount of memory (RAM),
2. a high number of cores to be computed in a short amount of time and
3. a large hard drive to store the simulation results.

These requirements can be met by:

1. large shared memory machines, or
2. computer clusters.

Often, such computational resources are not available locally, and there is a need for on-demand availability of computer resources in the cloud.

Large computational resources are also required in parameter studies. In parameter studies, a single computation may not require extraordinary resources and may run on a standard computer. However, there is often the need to vary many parameters. As an example, optimize a nonwoven filter material by creating various 3D structure models in **FiberGeo** and determine the filtration efficiency and pressure drop with **FilterDict** for each of them.



Assuming that a **FilterDict** simulation on such a 3D model takes 2 days to accomplish, and that 100 different parameter sets are to be tested, it would take 200 days on a single computer to perform the whole parameter study. However, by using computational resources in the cloud, it is possible to start all 100 simulations at once and finish the complete study in just 2 days.

SHARED MEMORY MACHINES

Large shared memory machines are single computers with a lot of RAM, many CPU cores and one or more large hard drives. These machines have the advantage that they are relatively cheap to purchase and easy to maintain. They allow to perform and visualize simulations on very large structures. Shared memory machines are the best option for most of the application cases. Recommendations about the hardware configurations for different use cases can be found at:

<https://www.geodict.com/service-support/technical-support/system-requirements.html>

The operating system on these machines is often Windows or Linux. Typically, one or more users can login to this computer at the same time with a remote desktop connection. The most used combinations are:

1. Local Windows to remote Windows can be done with Microsoft's built-in *Remote Desktop Connection* tool.
2. Local Linux to remote Linux can be done with the built-in *SSH* command line tool or TurboVNC which is a graphical remote desktop connection tool.
3. Local Windows to remote Linux can also be done with TurboVNC.

The graphical remote desktop connection with TurboVNC is a very convenient way to perform simulations on shared memory machines, but TurboVNC is not a built-in tool. On page [10](#), we describe the installation and usage of this tool.

COMPUTER CLUSTERS

Sometimes structures are very large (e.g., 4096³) and even large shared memory machines do not have enough memory to perform a flow or mechanical simulation. In this situation a computer cluster with many compute nodes is required.

A computer cluster typically consists of compute nodes with same hardware configuration and they are communicating with each other over a very fast interconnection (e.g. InfiniBand). With a floating license, it is possible to use GeoDict with its GUI on such clusters but typically a simulation script is submitted into a job queue management system.

A job queue scheduler is a computer application for controlling unattended background program execution of jobs. This is commonly called batch scheduling, as execution of non-interactive jobs is often called batch processing. Two commonly used job schedulers are:

1. Portable Batch System (PBS)
2. Slurm Workload Manager (SLURM)

Both schedulers can be used to submit and perform GeoDict simulation jobs.

PBS is the name of computer software that performs job scheduling. Its primary task is to allocate computational tasks, i.e., batch jobs, among the available computing resources. It is often used in conjunction with UNIX cluster environments.

The Slurm Workload Manager is a free and open-source job scheduler for Linux and Unix-like kernels, used by many of the world's supercomputers and computer clusters.

On page [14](#), we describe how to submit jobs on both systems.

CLOUD SERVICES

Cloud computing describes a model that provides shared computer resources as a service on demand: for example, in the form of servers, data storage or applications.

Usually, it is possible to lease large shared memory machines or cluster-like environments. These shared memory machines can also be used as virtual machines that allow remote desktop connections. The prices depend on the hardware configuration. Cloud computing can be a good alternative to purchasing an own


computer system depending on the total usage per year. Especially for peak times it can make sense to supplement the computer resources by cloud computing.

To use **GeoDict** in a cloud environment of the user's choice, a **GeoDict** cloud floating license is required. The floating license server must be set up such that it is accessible from within the cloud environment of the user. In this scenario, the user must purchase cloud resources directly from a cloud service provider, and install and set up **GeoDict** in the cloud himself.

To simplify cloud access, Math2Market offers two cloud solutions directly, the **GeoDict Cloud** and the **Math2Market Cloud**. In these setups, the user does not need to install **GeoDict** in the cloud, and access to cloud resources is provided by Math2Market.

GEODICT CLOUD

GeoDict 2023 gives users the choice to run computations locally or in the cloud. Besides the **Run** button which starts the computation on the local computer, the **Run in Cloud** button allows to submit the simulation into the cloud.



This is done in cooperation with the Swiss company KaleidoSim (<https://kaleidosim.com/>). KaleidoSim is a specialist in scientific computing in the cloud. In 2020, Math2Market started to offer cloud solutions to customers together with KaleidoSim. This cloud solution frees the user from the constraints of limited local resources.

The **GeoDict** cloud offers a simple web framework that allows users to create parameter studies, run the simulations there, and retrieve the data again for detailed analysis locally.

GPU compute instances are offered as well, so that the AI capabilities of **GeoDict** (e.g., **GeoDict-AI**, **FiberFind-AI**, **ImportGeo-VOL**) can also be fully utilized.

This solution is described in detail on page [17](#).

MATH2MARKET CLOUD


The Math2Market Cloud solution offers the full experience of **GeoDict** without any installation or hardware requirements. Only a web browser and an internet connection are needed to use **GeoDict**.

Though your web browser, you will be able to log into your account and access your individual Math2Market Cloud Dashboard. On this dashboard, you may start a virtual

machine in the Math2Market Cloud, where GeoDict is already installed and ready-to-use.

A virtual machine (VM) is a virtual workstation in the Math2Market Cloud that is simply create with a few click through your Math2Market Cloud dashboard.

Connection to the VM occurs via this dashboard and then, the desktop of the VM is reached without leaving your browser. The VM desktop has the look and feel of a real workstation: simply click on the GeoDict icon found on the desktop to start a GeoDict instance on your VM.





This solution is described in detail on page [27](#).

PARALLELIZATION AND CONFIGURATION OF MPI


The solvers in **GeoDict** can make use of powerful hardware by parallelization of simulations to decrease the runtime.

PARALLELIZATION OPTIONS


The parallelization can be configured in the parallelization dialog. This dialog is available in the solver tabs of all **Dict** modules:




When **Local, Sequential** is selected, no further parameters are needed and the solver runs sequential without parallelization. This option can be useful for very small structures.



When **Local, Parallel** is selected, the **Number of Processes** can be entered. Then the maximum number of available processors and the maximum number of licensed parallel processes is shown in the dialog. The solver runs parallel with the specified number of processes / threads.



When **Local, Maximum** is selected, the maximum number of available and licensed processors / threads is used for the simulation. This is the default option and in most cases the best choice.



The choice of **Cluster** is for users of Linux clusters. Then the number of compute nodes and the number of processes per node can be entered. The solver runs parallel and distributes the simulation over different compute nodes.

Not all solvers support all parallelization options, as shown in the following table:

Solver	Parallelization Option			
	Local, Sequential	Local, Parallel	Local, Maximum	Cluster
EJ solver	✓	✓	✓	✓
SimpleFFT solver	✓	✓	✓	✓
LIR solver	✓	✓	✓	✗
FeelMath solver	✓	✓	✓	✓
Particle tracker	✓	✓	✓	✓
BEST solver	✓	✓	✓	✗

The parallelization of the solvers is done with three technical methods:

1. Local-MPI parallelization,
2. Distributed-MPI parallelization, and
3. Local-Thread parallelization.

MPI stands for Message Passing Interface and is a standardized and portable message-passing standard designed by a group of researchers from academia and industry to function on a wide variety of parallel computing architectures. Solvers (e.g. EJ or SimpleFFT) that use MPI are started multiple times as different instances. Each instance performs a simulation on a sub-volume of the whole structure. MPI is used to send data of intermediate results between the running instances. Local-MPI parallelization works within the same computer while Distributed-MPI works across different computers. When Local-MPI is used then the sending of data can be done very efficiently because its running on the same machine while Distributed-MPI has to use Ethernet or fast interconnection like InfiniBand to send data between different computers.

The LIR solver and BEST solver use Local-Thread parallelization. These solvers are started only once per simulation and data does not have to be sent between instances because there is only one. But these solvers cannot use multiple compute nodes of a cluster to distribute the simulation data.

The following table shows the support of both parallelization methods:

The **Cluster** parallelization requires that the solver supports the MPI parallelization method. The **Local, Parallel** parallelization can be done with MPI parallelization or Thread parallelization.

Solver	Parallelization method	
	MPI Parallel	Thread Parallel
EJ solver	✓	✗
SimpleFFT solver	✓	✗
LIR solver	✗	✓
FeelMath solver	✓	✓
Particle tracker	✓	✓
BEST solver	✗	✓

An important difference between thread and MPI parallelization is that thread parallelization does not need any special installation procedure. It is available on all operating systems and hardware architectures. MPI parallelization requires the installation of an MPI software package.

INSTALLATION OF MPI

GeoDict MPI parallel solvers support three MPI software packages:

1. MPICH-3 for Linux (<https://www.mpich.org/>),
2. OpenMPI-1.10.7 for Linux (<https://www.open-mpi.org/>), and
3. Microsoft MPI for Windows.

The Microsoft MPI is automatically installed during the GeoDict installation. MPICH3 or OpenMPI are often available on Linux system but sometimes it has to be manually installed by the user.

Installation of MPI under Linux is possible using the command line or you can trigger the installation from the GeoDict GUI.

To install MPI from the command line open a terminal and change the current directory into the GeoDict installation folder. The installation folder contains a shell script with the name *setupMPI.sh*. Execute this script with the command:


```
./setupMPI.sh
```

The script compiles MPICH-3.2 and OpenMPI-1.10.7 and installs them in the GeoDict installation folder in the sub-folder *MPI*. Root permission is not required to perform this installation procedure, but the compiled MPI packages are available for the current GeoDict installation only. It is also possible to make the MPI packages available for the whole system. This can be done by using the command line argument *root*, i.e.

```
sudo ./setupMPI.sh root
```

Here, root permission is required and the MPI packages are installed in `/usr/local/`. GeoDict then automatically detects and uses MPI for parallelization after installation.

It is also possible to trigger the script `./setupMPI.sh` from GeoDict's user interface, and in this case MPI will be installed locally (the root version is not available from the GUI). For this, choose **Settings** → **Settings** from the main menu of GeoDict. To install, click on **Install MPI** in the **Solver MPI Parallelization** panel.




The compilation and installation of MPI will take approximately 15 to 30 minutes. After the installation, check if the OpenMPI and Mpich3.2. executables have been created, as the script will not return an error message if one of the installations fails.


SWITCH BETWEEN DIFFERENT MPI PACKAGES

MPICH-3.2 is used by default in Linux but sometimes OpenMPI-1.10.7 might be a better choice in computer cluster environments. Many clusters have InfiniBand interconnection between the compute nodes. Unfortunately, MPICH-3 cannot use this interconnection natively and therefore the scaling behavior might not be ideal for more than four compute nodes. OpenMPI-1.10.7 can use InfiniBand interconnections natively and provides a good scaling behavior beyond four compute nodes.

The choice of the used MPI package can be changed by setting **MPI Installation** to **Manual** and browsing to the corresponding **mpixec** executable of the selected MPI version.



If set as above, **GeoDict** solvers will use MPICH 3.2 installed in /usr/local for parallelization. It is possible to check if the desired MPI package is used by inspection of the command line output of **GeoDict** when an MPI parallel solver is started. For Mpich 3.2, the command line output should look similar to:



```
Console
Arguments: ['local', 'simplefft_parallel', 'SolverParameters_z.pde', '8', '1', 'machines.txt', '', '', '', '', '', '', '', '', '', ''
Current Dir: /home/becker/MyFirstGeoDictProject/StokesResult
MPI: installed in /home/becker/Downloads/GeoDict2023-Rev61942-Linux-2023-01-13/MPI/mpich-3.2/bin/mpiexec (version: Mpich3)
>>>> args[5] = machines.txt
>>>> args[5] = machines.txt
>>>> args[6] =
GeoDexcel path: /home/becker/Downloads/GeoDict2023-Rev61942-Linux-2023-01-13/GeoDexcel/GeoDexcel2023_LoadGDR.vbs
h264: [None, '-frames', 'SolverParameters_z.pde', '-fps', 'machines.txt', '1', '-o', '8_264']
mpi_arg: ['/home/becker/Downloads/GeoDict2023-Rev61942-Linux-2023-01-13/MPI/mpich-3.2/bin/mpiexec', '-machinefile', 'machines.txt']
cadexec: C:\Program Files\CADlook\CADlook64_V14.0\CADlook64.exe
fluent: C:\Program Files\ANSYS Inc\v221\fluent\ntbin\win64\fluent.exe
Solver Location: /home/becker/Downloads/GeoDict2023-Rev61942-Linux-2023-01-13/GD2023PdeSolverMpich3 found at /home/becker/Downloads/GeoDict
Command: ['/home/becker/Downloads/GeoDict2023-Rev61942-Linux-2023-01-13/MPI/mpich-3.2/bin/mpiexec', '-machinefile', 'machines.txt',
```

It is possible to add additional command line arguments to the MPI call by entering them in the MPI Command-line Arguments box in the Settings dialog. These additional command line arguments may be used to configure proper usage of the InfiniBand adapter or to show more debug information in the command line output. As an example for Mpich 3.2., the usage of the Internet Protocol over InfiniBand (IPoIB) feature can be configured with the command line argument: "-iface ib0".

GRAPHICAL REMOTE DESKTOP CONNECTION TO LINUX COMPUTER

A graphical remote desktop connection to a remote Linux computer can be used to run GeoDict on it. A GeoDict installation has to be available on the remote Linux computer, but not necessarily on the local Windows computer. Since GeoDict completely runs on the Linux computer all benefits from the Linux computer capabilities in each step, e.g., structure generation, property prediction, visualization and so on are available.

Follow these steps to use the remote desktop for GeoDict. Steps 1 to 3 are to set it up, and carried out only once. Steps 4 to 6 are done every time remote computations are performed:

1. Install TurboVNC on the remote Linux computer. TurboVNC is used as X proxy and video server. Further information of TurboVNC can be found here:
<http://www.turbovnc.org/>
2. Install and set up VirtualGL on the remote Linux computer. VirtualGL is used for hardware OpenGL support. Further information of VirtualGL can be found here:
<http://www.virtualgl.org/>
3. Install and set up TurboVNC on the local Windows computer.
4. Start TurboVNC server on the remote Linux computer.
5. Connect the Windows computer to the remote Linux computer.
6. Start and run GeoDict on the remote Linux computer.

INSTALL TURBOVNC ON THE REMOTE LINUX COMPUTER

The following description is valid for Ubuntu, and it might be slightly different for other Linux operating systems. For more information see:

<https://cdn.rawgit.com/TurboVNC/turbovnc/master/doc/index.html>

1. Download the appropriate TurboVNC binary package for your system from
<http://sourceforge.net/projects/turbovnc/files/2.2.6/>
e.g.
https://sourceforge.net/projects/turbovnc/files/2.2.6/turbovnc_2.2.6_amd64.deb
2. Install TurboVNC by switching (cd) to the directory where you downloaded TurboVNC and issuing the following command:

```
sudo dpkg -i turbovnc*.deb
```

INSTALL VIRTUALGL ON THE REMOTE LINUX COMPUTER

The following description is valid for Ubuntu running LightDM, and might be slightly different for other Linux operating systems. Further information can be found at:

<https://cdn.rawgit.com/VirtualGL/virtualgl/2.6.5/doc/index.html>

1. Download the appropriate VirtualGL binary package for your system from:
<https://sourceforge.net/projects/virtualgl/files/2.6.5/>
e.g.
https://sourceforge.net/projects/virtualgl/files/2.6.5/virtualgl_2.6.5_amd64.deb
2. Install VirtualGL by switching (cd) to the directory where you downloaded VirtualGL and issuing the following command:
`sudo dpkg -i virtualgl*.deb`
3. Configure the server:
 - a. Shut down the x server as follows (or restart computer later):
`sudo /etc/init.d/lightdm stop`
 - b. Run the following:
`sudo /opt/VirtualGL/bin/vglserver_config`
 - c. Select option 1 to configure the server.
 - d. Choose **no** for restriction.
 - e. Choose **yes** for disabling XTEST.
 - f. Start the x server again as follows (or restart computer):
`sudo /etc/init.d/lightdm start`
4. In order to get the Nvidia driver loading for remote computers, without having a monitor plugged in, open /etc/X11/xorg.conf with a text editor and add the option "ConnectedMonitor" "CRT" to the section "Device" just below the Driver "nvidia" line. In some linux distributions, the file /etc/X11/xorg.conf does not exist by default anymore.

```
Section "Device"
    Identifier      "Device0"
    Driver          "nvidia"
    ConnectedMonitor "CRT"
    VendorName     "NVIDIA Corporation"
EndSection
```

In such cases, please check where such an option should be added in your linux distribution.

INSTALL TURBOVNC ON THE LOCAL WINDOWS COMPUTER

Download and install TurboVNC-2.2.6-x64.exe from:

<https://sourceforge.net/projects/turbovnc/files/2.2.6/>

Further information can be found here:

<https://cdn.rawgit.com/TurboVNC/turbovnc/master/doc/index.html>

Follow the instructions that are shown in the installation wizard (click "next" button).

START TURBOVNC SERVER ON THE LINUX COMPUTER

To set up the VNC server:

1. Open a ssh connection to the remote Linux computer, for example with **PuTTY**.
2. Enter: `/opt/TurboVNC/bin/vncserver` or for non-default windows size use the parameter `-geometry <width>x<height>`,


For example, enter:

```
/opt/TurboVNC/bin/vncserver -geometry 1900x950
```

- a. A VNC password is requested when started for the first time.
 - Enter a VNC password.
 - Verify the password.
- b. Passwords can be changed later through:

```
/opt/TurboVNC/bin/vncpasswd.
```
- c. The connection information is returned, e.g.

Desktop 'TurboVNC: golem:13 (widera)'. The session number (here: 13) is needed later. The IP address of this host is 192.168.1.39.



```
widera@golem: ~  
widera@golem:~$ /opt/TurboVNC/bin/vncserver  
Desktop 'TurboVNC: golem:13 (widera)' started on display golem:13  
Starting applications specified in /home/widera/.vnc/xstartup.turbovnc  
Log file is /home/widera/.vnc/golem:13.log  
widera@golem:~$ █
```

3. The ssh connection can be closed now.

This server stays open as long as you do not log-out the virtual session. A virtual session can be stopped by entering:

```
/opt/TurboVNC/bin/vncserver -kill :“your session number”.
```


The active VNC servers can be listed by entering:

```
/opt/TurboVNC/bin/vncserver -list.
```



CONNECT WINDOWS TO A REMOTE LINUX COMPUTER

As long as a virtual session exists (i.e., you have followed [these steps](#) and have not logged-out or killed the session), the connection to the remote Linux computer is established as follows:

1. Start the TurboVNC Viewer.
2. Enter the session server, either by its hostname or IP address followed by the session number, e.g., 192.168.1.39:13, and click **Connect**.



3. Enter your VNC password and click **OK**.



A virtual desktop of the remote Linux computer opens.

START AND RUN GEODICT ON THE REMOTE LINUX COMPUTER

VirtualGL is used to redirect rendering to the remote graphics hardware, meaning that **GeoDict's** graphical user interface is available in the Linux computer.

To start **GeoDict**, open a terminal and enter:

```
vglrun ./YourGeoDictPath/geodict2023
```

The started **GeoDict** session on the remote Linux computer is maintained until the user logs out or kills the VNC session. Otherwise, the user can close the remote desktop dialog box (by clicking on the x in the upper right corner), turn-off the local Windows computer, go home, and restart the remote session later, finding that the started **GeoDict** jobs are still running.

CLUSTER COMPUTING ON LINUX CLUSTERS

Many prediction modules (e.g. FlowDict) allow to perform computations on Linux clusters. This allows to utilize many compute nodes at the same time to massively parallelize large computations.

In this case, GeoDict needs to be installed on each compute node or it has to be installed on a shared file systems such that each compute node can access it. A floating license installed in a license server is needed and each compute node must have access to the license server. Node-locked licenses do not work for cluster computing.

Three steps are needed to start large simulations on a Linux cluster:

1. Enable password-less login on cluster compute nodes.
2. Prepare a cluster simulation script.
3. Submit a simulation on the cluster.

ENABLE PASSWORD-LESS LOGIN

When using SSH to login to (other) cluster nodes, the system typically asks for a password. This is bothersome for multi-process job startup procedures. However, the SSH configuration can be changed to allow password-less login to cluster compute nodes. The script *enablePasswordLessLogin.sh* configures that for you:

1. Switch to the GeoDict installation folder.
2. Execute `./enablePasswordLessLogin.sh`

This script has to be executed when logged in to your Linux account on the cluster. It can also be done on your "local" Linux computer, if your local computer and the cluster share the same account. After execution of the script, it is possible to login to cluster node without password input.

PREPARE A CLUSTER SIMULATION SCRIPT

A submission shell script is needed to start a simulation on a cluster. This shell script contains control information for the job submission system (e.g. number of nodes) and calls GeoDict with a floating license and a simulation script. A template for such a script is available in the GeoDict installation folder (Linux version only) with the name :

- *PBSClusterSimulationTemplate.sh* for PBS, and
- *SLURMClusterSimulationTemplate.sh* for SLURM.

The following description considers PBS but is very similar for SLURM.

```

1 #!/bin/bash
2
3 #####
4 # The following lines starting with PBS are not comments but internal commands for the queue-system
5 #
6 #####
7 # If an error happens do not restart the job
8 #PBS -r n
9
10 # Name of the job in the queue
11 #PBS -N GeoDictClusterSimulation
12
13 # Name of the Std-Out-Files
14 #PBS -o GeoDictClusterSimulation.out
15
16 # Name of the Std-Err-Files
17 #PBS -e GeoDictClusterSimulation.err
18
19 # 8 Nodes with 4 processes per node for 48 hour (adjust according to your needs)
20 #PBS -l walltime=48:0:0
21 #PBS -l nodes=8:ppn=4
22
23
24 #####
25 # The following lines need to be adjusted according to your GeoDict and MPI location #
26 # EXECUTE THIS SHELL SCRIPT WITH: qsub PBSClusterSimulationTemplate.sh #
27 #####
28
29 # Location of the MPI installation that should be used for the simulation
30 export PATH=~/GeoDict2023/MPI/mpich-3.2/bin/:$PATH
31
32 # GeoDict call script (adjust according to your GeoDict installation)
33 GEODICT=~/GeoDict2023/geodict2023
34
35 # GeoDict licence file (adjust according to your licence location)
36 LICENSE=~/geodict2023/geodict2023.lic
37
38 # Your simulation script that should be performed on the cluster
39 SIMULATIONSCRIPT=~/GeoDictClusterSimulation.py
40
41 #####
42 # The following lines start GeoDict and perform a cluster simulation
43 #
44 #####
45 $GEODICT $LICENSE $$SIMULATIONSCRIPT

```

- Adjust the following lines of the submission script according to your **GeoDict** installation and cluster settings:
 - Line 20: Maximum runtime of the simulation. If the simulation last longer than the specified runtime than the job is cancelled.
 - Line 21: Number of nodes and processes per nodes (ppn).
 - Line 30: Path to your MPI installation.
 - Line 33: Path to your **GeoDict** installation.
 - Line 36: Path to your **GeoDict** floating license.
 - Line 39: Path to your simulation script.
- Create a simulation script that performs the simulation. Make sure that the parallelization settings in the simulation script use the cluster, e.g.:

```

1 'Parallelization' : {
2   'Mode'           : 'CLUSTER',
3   'NumberOfNodes' : 8,
4   'ProcessorsPerNode' : 4,
5 }

```

- Line 3: Number of nodes. This number has to be smaller or equal to the number of nodes in the submission script.
- Line 4: Processes per node. This number has to be smaller or equal to the number of processes per node in the submission script.

START A SIMULATION ON THE CLUSTER


1. Login to the master node of the cluster (e.g. with putty or SSH)
2. Change the working directory to the submission shell script.
3. Make sure that enough disk space is available for temporary saving of flow fields
4. For PBS: Start the simulation with the command:

```
qsub <Path to Shell Script Folder>/ PBSClusterSimulationTemplate .sh
```
5. For SLURM: Start the simulation with the command:

```
sbatch <Path to Script Folder>/ SLURMClusterSimulationTemplate.sh
```
6. A log file for the simulation run is created with the name **GeoDictClusterSimulation.out**

CHOICE OF COMPUTE NODES

When using a job submission system, it is not a priori known which compute nodes will be used for the computation, the job system will make that decision when starting the job depending on which nodes are available at that moment. The mechanism used by PBS and SLURM to pass the information about the assigned compute nodes to MPI is as follows. The job system will create a file containing a list of the signed compute nodes. The path to this file will be set as an environment variable, typically named PBS_NODEFILE. If another job submission system is used, which may use a different variable name, GeoDict allows to change the name of the environment variable in the **Settings->Settings** dialog.



This mechanism can also be exploited to allow for a manual choice of the compute nodes, e.g. when no job submission system is used:

1. You have to create your own "node" file. Create a text file and fill it with the names of the computers that should be used for the computation, e.g.
node001
node002
node003
The names are separated by newlines.
2. Set the path to the node file as value for the PBS_NODEFILE variable. This can be done with the Linux command: `export PBS_NODEFILE=<path to node file>`
This command has to be executed before GeoDict is started.
3. Then follow the instructions described above to start a distributed simulation.

CLOUD COMPUTING

GEO DICT CLOUD

GeoDict 2023 gives users the choice to submit computations to the cloud. using the **Run in Cloud** button.

This is done in cooperation with KaleidoSim, and more information can be found on their webpage <https://kaleidosim.com/products/application/geodict/>

REGISTRATION

To register for this cloud service, please contact our support at support@math2market.de for more information.

Before you can use the **Run in Cloud** button, an account must be created for your organization.

When you are added as user in your organizations account, you will receive an invitation email. After clicking on the link in the email, a registration form will open in your web browser.

GEO DICT

Registration
Register now to experience the best in advanced computational engineering.

First name

Last name

Email

Select Country

+41

Password

Repeat password

I agree to the the privacy agreement + Terms and conditions.

I'm not a robot

RCAPTCHA
Privacy - Terms

Create Account


Do you already have an account? [Login](#)

Enter your data to register in your organizations account. After you have created your account, you are set to use the **Run in Cloud** button from GeoDict.

Be aware that additional pay-per-use costs are associated with using the GeoDict cloud.


RUNNING A SINGLE SIMULATION IN THE CLOUD

To start a simulation in the cloud, enter the simulation parameters as usual in GeoDict by clicking on the Options **Edit...** button.




After setting up of the parameters, click the **Run in Cloud** button instead of the **Run** button.

Then, enter your credentials in the pop-up dialog. The Username is your mail address, and the password is the one you selected when registering.



After entering your credentials, the **Run Command in GeoDict Cloud** dialog opens.




The **Project Name** is the name of the current project folder in GeoDict. Enter a **Case Name Prefix** that is used to identify the simulation later.

The two checkboxes **Upload Current Structure** and **Upload Current Project Folder** are selected or un-selected automatically depending on the simulation to run.

Select the **GeoDict Version** (should be same as local GeoDict version) and the **GeoDict License**. Only licenses that Math2Market has made available for the specific user are shown here. Typically, just a single license will be available for a user.

Select a Machine

Click on **Select...** to open a dialog that let's you select a machine that is sufficient for your job.




Select a machine that has enough **RAM (GiB)** available to run the job. If you are in doubt how much memory is required, you may run **Estimate Memory** prior to **Run in Cloud**. If the machine does not have enough RAM, executing the job will fail.

Select **# cores** available to run the job. You must select at least as many as selected in the Parallelization dialog. Be aware that the **# cores** shown includes cores available through the use of hyperthreading. That means, a machine with # cores equal to 32 consists of 16 real cores. Many GeoDict jobs cannot efficiently use hyperthreading, their speed is limited by the ability of the processor to process large amount of data, and not by the ability to do many arithmetic operations. Therefore, if you select a machine with 32 cores from the list, the runtimes may be similar for using 16x parallelization or 32x parallelization, as cores available through hyperthreading do not add a significant speedup.

High performance computing for GeoDict

For AI applications using the Tensorflow python library, e.g. FiberFind-AI, it is possible to select a machine with one or several GPUs. Enter the **Number of GPUs** in the box above to receive a selection of machines with the requested number of GPUs.




The **vCPU-hours per hour** are the costs associated with the selected machine, and depend on the number of cores, Ram and GPUs available.


The selected machine will be stopped automatically, after the simulation run is finished. Setting a **Timeout** ensures that the simulation is cancelled and the selected machine is stopped after the selected time.

Start the simulation

Click on the **Run** button to start the simulation. The **GeoDict Cloud Projects** dialog appears:



The job is now transferred to the cloud and solved on the designated machine. You may close the dialog and continue to work with **GeoDict**. Open the dialog any time by selecting **Macro – GeoDict Cloud Projects...** in the main menu.



To update the shown status and used vCPUh information, it is necessary to click on the **Refresh** button.

Terminate Simulation(s) stops the selected simulation(s).

Delete Project removes a project from the list. The **GeoDict Cloud Projects** dialog always lists all projects accessible in the KaleidoSim account of the user, including simulations and projects started in previous **GeoDict** sessions.

The KaleidoSim Dashboard

Click on **Open in Browser...** to access the KaleidoSim dashboard (This step is not necessary to run the simulation, the whole simulation process can also be managed from within the **GeoDict Cloud Projects** dialog). The dashboard gives direct access to the user profile and the users projects on KaleidoSim.

The screenshot shows the GEO DICT Dashboard. The 'Project Cases' section contains a table with the following data:


Case	Input File	Status	Case results	Actions
<input type="checkbox"/> User Guide Testcase	case.zip	Starting your machine	n/a	

Click on **Projects** and select your project to access the **Project Cases** box. Inside the box, the current status of the simulation is shown. During a simulation run, it will move through various stages until finally arriving at "Completed".


Clicking on the **Detail** toolbutton (the eye symbol) shows more details of the running simulation, including the current log output.

Download Results

When the simulation is completed, it will be shown both on the dashboard




and (after **Refresh**) in the dialog window:



The dialog will also show the **Used vCPUh** of the simulation run, which determines the costs. When the simulation is completed, the simulation results are located in the KaleidoSim cloud, not on the local machine. To download the results, click **Download Results...** and another dialog will open that lets you select which files to download.

It is advisable to download at least all .gdr files.

Select the files to download and the location on your local machine.




To open the result file locally, select **File** → **Open Results (*.gdr)** in GeoDict's main menu and browse to the downloaded gdr file. The results will then show in your local GeoDict. Remember, that some visualization options may only be available if additional files located in the corresponding subfolder are also downloaded, e.g., in the shown example, streamlines can only be visualized if the file *FlowField_z.vap* is also downloaded.


Clicking on **Show log...** opens the logfile in another dialog.

RUNNING PARAMETER STUDIES IN THE CLOUD

Besides running a single simulation in the cloud, it is possible to start several simulations at once in a parameter study. Select **Macro -> Execute Macro / Script** in the main menu and open the **Macro Execution Control** dialog.



Select the macro to run (it must be a macro containing variables), check **Vary** and open the **Parameters** selection. After entering a list of parameters, click **Run in Cloud** and the **Run GeoPython Macro in GeoDict Cloud** dialog opens:



The dialog is similar to the **Run Command in GeoDict Cloud** dialog described on page 18. Here, the **Upload Current Structure** and **Upload Current Project Folder** boxes are selectable.

Select **Upload Current Structure** if the macro operates on the current structure. If all structure models are generated in the macro run itself, it is not necessary to upload the current structure.

Select **Upload Current Project Folder** if the macro depends on files stored in the local project folder, e.g. structure files are loaded in the macro run.

At the bottom of the dialog, the **Variable Variation** table gives an overview over all simulations and the selected parameters.

Click **Run** to start the simulation in the cloud. The simulations will not be started sequentially on a single machine, but parallel on multiple machines of the selected type. The **GeoDict Cloud Projects** dialog shows the current state of each simulation:


The top screenshot shows the 'GeoDict Cloud Projects' dialog with the following table:

Name	Created	Used vCPUh	Status
▼ HPC	2023-05-08 13:50:54	4.8	Unfinished
User Guide Test gd_svp=10 gd_diam=7		0.5	Simulation Running
User Guide Test gd_svp=10 gd_diam=9		0.5	Simulation Running
User Guide Test gd_svp=10 gd_diam=11		0.5	Archiving results
User Guide Test gd_svp=12 gd_diam=7		0.5	Simulation Running
User Guide Test gd_svp=12 gd_diam=9		0.5	Archiving results
User Guide Test gd_svp=12 gd_diam=11		0.5	Archiving results
User Guide Test gd_svp=15 gd_diam=7		0.5	Simulation Running
User Guide Test gd_svp=15 gd_diam=9		0.5	Simulation Running
User Guide Test gd_svp=15 gd_diam=11		0.5	Simulation Running

The bottom screenshot shows the same dialog with the following table:

Name	Created	Used vCPUh	Status
▼ HPC	2023-05-08 13:50:54	4.9	Completed
User Guide Test gd_svp=10 gd_diam=7		0.5	Completed
User Guide Test gd_svp=10 gd_diam=9		0.6	Completed
User Guide Test gd_svp=10 gd_diam=11		0.5	Completed
User Guide Test gd_svp=12 gd_diam=7		0.6	Completed
User Guide Test gd_svp=12 gd_diam=9		0.5	Completed
User Guide Test gd_svp=12 gd_diam=11		0.5	Completed
User Guide Test gd_svp=15 gd_diam=7		0.6	Completed
User Guide Test gd_svp=15 gd_diam=9		0.5	Completed
User Guide Test gd_svp=15 gd_diam=11		0.5	Completed

When all simulations are finished, click **Download Results** and select which type of results you want to download to your local computer.



The downloaded files will appear unzipped in the selected folder.

MATH2MARKET CLOUD

With the Math2Market Cloud solution, only a web browser and an internet connection are needed to use GeoDict. Through your web browser, you will be able to log into your account and access your individual Math2Market Cloud Dashboard. On this dashboard, you may start a virtual machine in the Math2Market Cloud, where GeoDict is already installed and ready-to-use.

Please contact support@math2market.de for more information.

LOG INTO YOUR M2M CLOUD VM WORKSTATION

You will receive an email from accounts@cloud.math2market.de with your login data (username and password). The link included in this email gives access to the Math2Market Cloud webpage.


In this webpage, enter the login data (username and password).

If multi-factor authentication is required for your account, a second identification (e.g. through a token generated with the Google authenticator app on your smartphone) will be necessary.

Afterwards, your individual Math2Market Cloud dashboard appears. Note that in case of high load, the log in process may take a few seconds.

MANAGE DATA IN THE DASHBOARD

Your dashboard contains four buttons in the upper right corner:



- Dashboard: this overview page.
- Change Password: page to change your password.
- MFA setting: page to handle multi-factor authentication settings.
- Logout.

and two panels below:

Running virtual workstations

Running virtual workstations

Status	Password	Hostname	vCPUs	RAM [GiB]	CPU usage	RAM usage	Disk usage	Launch time	Time running [dd:hh:mm]	Terminate
Start empty workstation										

This panel contains a list of your currently running virtual workstations. The first column **Status** will specify the current position of the lifecycle of the cloud workstation.

You can start a cloud workstation by clicking the green **Start empty workstation** button.

Project Data

Project data

Name	Size [GiB]	Time of upload	Start workstation with data	Delete
Upload ZIP...				

The panel contains a list of currently available data archives (.zip) in the Math2Market cloud. Zipped data archives shown in this panel of the dashboard come from these sources:

- From your local computer for upload to the cloud. This is done by clicking **Upload ZIP** (in this panel) to select a zip file.

The screenshot shows the MATH 2 MARKET dashboard. At the top left is the logo. On the top right are navigation buttons: Dashboard, Change password, MFA settings, and Logout. Below the logo, there is a text input field for 'Upload ZIP file:' with a 'Browse...' button and the filename 'DataForCloud.zip'. To the right of the filename is an 'Upload' button.

Afterwards, the uploaded data is shown in the **Project data** panel.

Project data

Name	Size [GiB]	Time of upload	Start workstation with data	Delete
DataForCloud.zip	0.0	April 17, 2023, 1:52 p.m.	Start workstation	
Upload ZIP...				

- From the project folder of a running VM workstation. This is done by double-clicking the **copyProjectFolderToDashboard** script on the desktop of a running VM workstation. See page [31](#) for details.

By clicking on the green **Start workstation** button in the Project data panel, the content of this zipped data archive will be extracted to your default project folder (/home/geodict/MyFirstGeoDictProject) on that machine. The archive name will not be used as its own folder within the virtual machine.

The ZIP files in the **Project data** panel (thus, from the Math2Market cloud) can be downloaded to your local computer by clicking on their filename, shown in blue.

A ZIP archive from the **Project data** panel might be deleted by clicking the red trash can that will appear on the right-hand side of the row.

CREATE A NEW M2M CLOUD VM WORKSTATION

After clicking the **Start workstation** button in the **Project data** panel or the **Start empty workstation** button in the **Running virtual workstations** panel, select a machine type:

Name	# of cores	RAM size [GiB]	GPU
r5.large	2	16	X
r5.xlarge	4	32	X
r5.2xlarge	8	64	X
r5.4xlarge	16	128	X

Select a machine by clicking on the blue type name. A new Cloud VM workstation is created.


Status	Password	Hostname	vCPUs	RAM [GiB]	CPU usage	RAM usage	Disk usage	Launch time	Time running [dd:hh:mm]	Terminate
Starting	Show	owkgbbcj	2	16	?	?	?	?	None	X

Start empty workstation

After a short loading time, a new row appears in the list of **Running virtual workstations** panel. The creation of a Cloud VM workstation may take up to 1-2 minutes.

When the Cloud VM workstation is ready to use, the workstation **Status** changes from **Starting** to **Connect** and turns from orange to a green, clickable button.

Running virtual workstations




Status	Password	Hostname	vCPUs	RAM [GiB]	CPU usage	RAM usage	Disk usage	Launch time	Time running [dd:hh:mm]	Terminate
Connect	Show	owkgbbcj	2	16	5.9%	4.1%	0.0%	14:02:52 Apr 17, 2023	00:00:06	X

Start empty workstation

ACCESS THE CREATED M2M CLOUD VM WORKSTATION

The newly created VM workstation will be accessed by clicking on the green **Connect** button under **Status**.

For this, a password will be needed to access the VM in the next step. This password is displayed in a small dialog after clicking the green **Show** button.



Select and copy this password to your clipboard (Ctrl+C) and click **Close** to close the dialog.


Click now the green **Connect** button under **Status**.

In the new VNC browser tab, click **Connect**.

Paste the copied password (Ctrl+V) and click **Send Password** to connect to the desktop of your virtual workstation.



You have now access to your running Math2Market Cloud VM workstation.




START GEO_DICT IN THE NEW M2M CLOUD VM WORKSTATION

Start **GeoDict** by double-clicking the **GeoDict**-icon. Starting **GeoDict** may not be immediate, but take a few seconds.

If you started the M2M Cloud VM workstation with a ZIP archive from the **Project data** panel, the content of this archive can be found in `/home/geodict/MyFirstGeoDictProject`.

COPY RESULT DATA TO THE DASHBOARD


To copy **GeoDict** results to the **Math2Market Cloud Dashboard**, double-click **copyProjectFolderToDashboard.py** on the desktop. You will be prompted for a name. After clicking **OK**, you should see a progress bar during the copy process.



Once the window disappears, you should find these results as a ZIP file in the **Project Data** panel shortly after. From here, again, you can download it to your machine or start another workstation in the future with that data.

High performance computing for GeoDict

If you want to upload a specific folder instead of your whole project folder, simply right-click on the folder in the file manager and select **Copy folder to dashboard**. You will be prompted to enter a descriptive file name for the new archive to identify it later on.




The name should not contain any special characters (dot, comma, #, &, %, @, /, \, ...)

Project data

Name	Size [GiB]	Time of upload	Start workstation with data	Delete
DataForCloud.zip	0.0	April 17, 2023, 1:52 p.m.	Start workstation	
ProjectResults.zip	0.0	April 17, 2023, 2:23 p.m.	Start workstation	

[Upload ZIP...](#)

VIEWER SETTINGS FOR YOUR RUNNING M2M CLOUD VM WORKSTATION



A tab on the left-hand side of your Cloud VM workstation browser page gives access to the viewer settings.


Open the tab by clicking on the arrow symbol:




There, it is possible (for example) to change to full screen mode (press **Esc** to finish). This should be used if the VM size is not scaling with the browser window size

TERMINATE THE RUNNING M2M CLOUD VM WORKSTATION

A running Cloud VM does not stop even after closing the browser tab. Therefore, to avoid additional costs, you should always terminate an unused Cloud VM workstation! To do this, go back to the dashboard, to the **Running virtual workstations** panel and click the **X** button on the right-hand side. It will prompt you to be sure that you have saved all required files.



In the background, the **Status** changes to **Terminating**. Terminating a Cloud VM may take a minute or two. Now close the VNC browser tab.



Technical
documentation:

Sven Linden
Andreas Wiegmann
Jürgen Becker
Aaron Widera
Barbara Planas

MATH
2 MARKET

Math2Market GmbH

Richard-Wagner-Str. 1, 67655 Kaiserslautern, Germany
www.geodict.com